

MENU's For New 294-002-529 USB Control Box with Version 10.01 firmware.

Menu Function #	Category	Description	Default If User Adjustable	Bold X = Minimum Security Bold, Y = Optional Level based upon settings					
				Q-AMF Only	Q-AMF Level	Dist Level	Owner Level	Mech. Level	None
01	PROGRAM	Retrieve Program	-----						X
02	PROGRAM	View Program	-----						X
03	PROGRAM	Edit Program	-----						X
10	CLOCK	Display Clock	-----						X
11	CLOCK	Edit Clock	Current Date/Time						X
30	SECURITY	Set Security	-----		Y	Y	Y	Y	
31	SECURITY	Set Passwords	-----		Y	Y	Y	Y	
32	SECURITY	Enter / Exit Security Mode	-----						X
41	LANE	Lane Odometer	-----						X
50	LANE	LOG Book (Interpret via Windows Programmer V4.x)	First in First Out						X
63	LANE	CYCLE TIMER (Set per each run. Times 1 cycle)							X
66	CONFIG	Machine Type (Replaces Machine ID Jumpers)	Current Production				X		
67	CONFIG	Select Drive Motor Type	-10 to 10V				X		
70	ADJUSTMENT	Set Encoder Factor	1.02					X	
80	ADJUSTMENT	Pass 2 Start Distance	01.0						X
81	ADJUSTMENT	Adjust Foul Line Stop	00.5						X
82	ADJUSTMENT	Reversing Switch Brake Delay	0.10						X
83	ADJUSTMENT	Calculate Speed Factor	-----						X
84	ADJUSTMENT	Edit Speed Factor	1.00						X
85	CONFIG	Change to HVO Summit or HVO Magnum Select	HVO Summit						X
86	ADJUSTMENT	Select 1, 2, or 3 Vac Head Shakes	1						X
87	ADJUSTMENT	Cleaner Pre-Stop Distance	08.0						X
88	ADJUSTMENT	Cleaner Pre-Start Distance	00.0						X
89	CONFIG	Cleaner Drip Mode Recharge	OFF						X
90	CONFIG	Set Switch Type	HANDLE						X
91	ADJUSTMENT	Test Function	-----						X
92	ADJUSTMENT	Saturate	100%						X
93	ADJUSTMENT	Adjust Oil	-----						X
94	ADJUSTMENT	Adjust Buffer	-----						X
95	ADJUSTMENT	Adjust Cleaner Pad / Vacuum Head	-----						X
96	ADJUSTMENT	Cleaner Presoak	-----						X
97	CONFIG	Cleaner Drip or Spray Mode	1-SPRAY						X
98	CONFIG	Set Oil Delay 0, 1, or 2 Feet	0						X

Default Security = 1111 = Mechanic, 2222 = Owner.

MSB un-editable. Xyyyy where X = Level & Y = 4 digit editable password.

Password 12345 = Mechanic Level 1 plus 2345

Password 22345 = Owner Level 2 plus 2345 editable password